

# FLEX I/O Thermocouple/RTD/ Millivolt Input Module

Catalog Numbers 1794-IRT8,1794-IRT8XT



by **ROCKWELL AUTOMATION** 

**User Manual** 

**Original Instructions** 

# **Important User Information**

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



**WARNING:** Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

**IMPORTANT** Identifies information that is critical for successful application and understanding of the product.

These labels may also be on or inside the equipment to provide specific precautions.



**SHOCK HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



**BURN HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



**ARC FLASH HAZARD:** Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

The following icon may appear in the text of this document.



Identifies information that is useful and can help to make a process easier to do or easier to understand.

Rockwell Automation recognizes that some of the terms that are currently used in our industry and in this publication are not in alignment with the movement toward inclusive language in technology. We are proactively collaborating with industry peers to find alternatives to such terms and making changes to our products and content. Please excuse the use of such terms in our content while we implement these changes.

# Preface

5
5
5
5

## Chapter 1

Overview	. 7
The FLEX System	. 7
Types of Modules	. 7
What the FLEX I/O Input Module Does	. 8
The FLEX I/O Module in a Logix Control System	. 8
Physical Features of Your Module	. 9

## **Chapter 2**

	44
Uverview	
Before You Install Your Module	11
Series A and Series B	11
Power Requirements	12
Install the Module	12
Mount on a DIN Rail	13
Mount on a Panel or Wall	14
Mount the FLEX I/O Module on the Terminal Base Unit	16
Wiring Information	17
Connect Wiring to the FLEX I/O Module	17
Identify RTD Wire Pairs	17

## **Chapter 3**

Overview	21
Add and Configure the FLEX I/O Module	21

## **Chapter 4**

Overview	25
Configure Your Input Module	25
Configurable Options and Their Effect on the Channels	25
Options that Affect All Channels.	25
Options that Affect Each Group of Four Inputs	26
Sensor Types	27
Read Data From the Module	27
Map Data for the Module	28
Block-transfer Read and Write	28
Series A Functionality in a Series B Module	33

# Overview of FLEX I/O and Your Thermocouple, RTD, and Millivolt Input Module

# Install Your FLEX I/O Input Module

# Configure Your FLEX I/O Module with RSLogix 5000 Software

Read and Write Configuration Maps for the FLEX I/O Module

	Chapter 5	
Calibrate Your Module	Overview	35
	When and How to Calibrate Your FLEX I/O Module	35
	Tools and Equipment	35
	Calibrate Your Input Module	35
	Calibration Setup	36
	Read and Write Words for Calibration	37
	Offset Calibration	39
	Gain Calibration	39
	Current Source Calibration	40
	Cold Junction Calibration	40
	Channel Loop Compensation Calibration.	41
	Appendix A	
Troubleshoot the Module	Overview	43
	Module Indicators	43
	Annendix B	
Electronic Nata Sheet (ENS) Files		/.⊑
	Undating FDS File	40 45
	FDS Installation	40 46
		U
	Appendix C	
Program Your Module with PLC	Overview	47
Family Processors	Enter Block Transfer Instructions	47
•	PLC-2 Family Processor	47
	PLC-3 Family Processor	47
	PLC-5 Family Processor	48
	PLC-5/250 Family Processor	49
	Appendix D	
Resolution Curves for	Type B Thermocouple	51
Thermocouples	Type E Thermocouple	52
	Type C Thermocouple	52
	Type J Thermocouple	53
	Type K Thermocouple	53
	Type R Thermocouple	54
	Type S Thermocouple	54
	Type T Thermocouple	55
	Type N Thermocouple	55
	Iype TXK/XK(L) Thermocouple	56
	Index	<b>-</b> 7
	inaex	5/

## **About This Publication**

This manual is a reference guide for the FLEX™ I/O Thermocouple, RTD, Millivolt Input Modules. It describes the procedures for installing, configuring, and troubleshooting your module.

## Download Firmware, AOP, EDS, and Other Files

**Summary of Changes** 

Download firmware, associated files (such as AOP, EDS, and DTM), and access product release

notes from the Product Compatibility and Download Center at rok.auto/pcdc.

This publication contains the following new or updated information. This list includes substantive updates only and is not intended to reflect all changes.

Торіс	Page
Updated template	throughout
Added inclusive terminology statement	2
Corrected wording in an Important table	18

## **Additional Resources**

These documents contain additional information concerning related products from Rockwell Automation. You can view or download publications at <u>rok.auto/literature</u>.

Resource	Description
FLEX I/O Thermocouple/RTD Input Analog Module Installation Instructions, publication <u>1794-IN050</u>	Information on how to install the Thermocouple/Millivolt Input Modules (1794-IRT8, 1794-IRT8XT).
EtherNet/IP Network Devices User Manual, publication ENET-UM006	Describes how to configure and use EtherNet/IP™ devices to communicate on the EtherNet/IP network.
ControlNet Network Configuration User Manual, publication CNET-UM001	Describes how to use ControlNet® communication modules with Logix 5000® controllers.
Ethernet Reference Manual, publication ENET-RM002	Describes basic Ethernet concepts, infrastructure components, and infrastructure features.
Industrial Automation Wiring and Grounding Guidelines, publication 1770-4.1	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, rok.auto/certifications	Provides declarations of conformity, certificates, and other certification details.

## Notes:

# Overview of FLEX I/O and Your Thermocouple, RTD, and Millivolt Input Module

## **Overview**

This chapter provides a description of the FLEX I/O Thermocouple, RTD, and Millivolt Input module and an overview of how it communicates with programmable controllers.

# **The FLEX System**

FLEX I/O is a small, modular I/O system for distributed applications that performs all functions of rack-based I/O. The FLEX system contains the following components shown:



Terminal base



I/O module

- Adapter Transfers read and write configuration data to and from the I/O module.
- Terminal base Contains a terminal strip to terminate wiring for two- or three-wire devices.
- I/O module Contains the bus interface and circuitry that is needed to perform specific functions that are related to your application.

The FLEX system consists of an adapter, terminal base unit, DIN rail, power supply, and adapter cabling components. You can use up to eight terminal bases per adapter.

For detailed instructions on how to set up and install your module, see <u>Install Your FLEX I/O Input</u> <u>Module on page 11</u>.

## **Types of Modules**

The module refers to the following catalogs:

Catalog Number	Voltage	Inputs	3 Description	
1794-IRT8	24V DC	8	Analog – 8 pt, 16 bit non-isolated RTD, thermocouple, and mV Input module	
1794-IRT8XT	24V DC	8	Analog – 8 pt, 16 bit non-isolated RTD, thermocouple, and mV Input module designed for extended temperature.	

The module accepts up to eight thermocouple or RTD inputs. The inputs are nonisolated and are selected with analog multiplexers. The inputs accept millivolt or resistive inputs. Default input spans are -40.00 mV... +100.00 mV or 0.0...500.0  $\Omega$ . Fault indicators are located field side.

No switches or jumpers are used on the TC and RTD Input module. The inputs have both fixed hardware filters and selectable firmware digital filters.

## What the FLEX I/O Input Module Does

The FLEX I/O Module in a

**Logix Control System** 

The module is a high-speed, high-accuracy temperature and millivolt measuring module that accepts thermocouple inputs, 2-, 3-, and 4-wire RTD inputs, and mV source inputs.

It offers the following:

- Wire-off, overrange, and underrange detection
- Good common mode rejection
- Usage with long thermocouple wiring
- Usage with grounded or ungrounded thermocouples

The Series B version of 1794-IRT8 provides capability to work with grounded thermocouples.

Use cold junction compensators (catalog number 1794-CJC2) in thermocouple mode. Two cold junction compensators are shipped with the 1794-IRT8.

The FLEX I/O Thermocouple, RTD, and Millivolt modules are intelligent modules that interface analog signals with Allen-Bradley<sup>®</sup> programmable controllers through a FLEX I/O adapter.

The adapter transfers data to and from the module. These transfers allow:

- The adapter to obtain input or output values and status from the module.
- Establishing the mode of operation through a process called configuration.

Figure 1 shows the flow of communication between the adapter and the I/O module.

#### Figure 1 - Typical Communication Between the Adapter and a Module



Figure 2 shows a broader view of how the FLEX I/O module interfaces with the different elements in a Logix system.

#### Figure 2 - FLEX I/O Modules in a Logix System



In this example, the FLEX I/O module communicates with the controller through the adapter. The controller can produce and consume tags. It can initiate MSG instructions that send and receive data or configure devices. Configuration of devices and the network is done through the personal computer running the controller and configuration software.

To learn about the prerequisites and steps to configure your FLEX I/O module using Studio 5000 Logix Designer<sup>®</sup> application<sup>(1)</sup>, see <u>Configure Your FLEX I/O Module with RSLogix 5000 Software on page 21</u>.



**Physical Features of Your** 

Module

**ATTENTION:** The following publications provide more information about EtherNet/IP, and ControlNet modules in a Logix 5000 system:

- EtherNet/IP Network Devices User Manual, publication ENET-UM006.
- ControlNet Network Configuration User Manual, publication <u>CNET-UM001</u>.

The module label identifies the keyswitch position, wiring, and module type. A removable label provides space for writing individual designations per your application. Indicators are provided to identify input fault conditions, and to show when power is applied to the module.

#### Figure 3 - Module Label and Indicators



Studio 5000 Logix Designer is the replacement for RSLogix 5000° (version 20 or later). It provides one software package for discrete, process, batch, motion, safety, and drive-based applications.

# Notes:

# Install Your FLEX I/O Input Module

#### **Overview**

## Before You Install Your Module

This chapter provides you with pre-installation requirements and instructions on how to install your FLEX I/O thermocouple, RTD, and millivolt input module.

Before installing your FLEX I/O Thermocouple, RTD, and mV module, you must:

- Verify that a suitable enclosure is available for installation of the module, and
- Position the keyswitch on the terminal base.

# ATTENTION:

- These modules do not receive primary operational power from the backplane. You must apply 24V DC power to your module before installation. If you don't apply power, the module position may appear to the adapter as an empty slot in your chassis.
- If using a Series B product to replace a Series A product, connect a wire between terminals 39 and 48 on the 1794-TB3G or 1794-TB3GS terminal base unit. If not connected, the Series B product defaults to Series B functionality.

## **Series A and Series B**

<u>Table 1</u> describes the differences between Series A and Series B of the FLEX I/O Thermocouple, RTD, and mV Input modules.

#### Table 1 - Series A and Series B Differences

Mode	1794-IRT8 Series A	1794-IRT8, 1794-IRT8XT Series B
Isolation	Between user side and system side	Between user 24V DC and user I/O; between user side and system side
Common Mode Range	<u>+</u> 4V DC	<u>+</u> 15V DC
Thermocouple Mode Wire-off Detection	When an open sensor is detected, data defaults to <b>maximum</b> value	When an open sensor is detected, data defaults to <b>minimum</b> value

#### ATTENTION:



- In the Studio 5000 Logix Designer application, if you use a series B product to replace a series A product, the module is accepted without an electronic key mismatch warning.
- This is true for 1794-IRT8 and 1794-IRT8XT modules that are installed on EtherNet/IP, ControlNet, or Remote I/O networks.
- The CJC Status bit, Read Word 9, Bit 3 are added with Firmware C release of the 1794-IRT8 Series B module.
- The CJC Status bit is turned on when the temperature between the CJCs is greater than 6  $^\circ\text{C}$  but less than 12  $^\circ\text{C}.$
- When this temperature difference is above 12 °C, then the CJC Alarm bits are set.
- If a CJC temperature is overrange or underrange the associated CJC Alarm bit is set. In this condition, the CJC Status bit is not set.
- The CJC Status bit did not exist in Series A.

# **Power Requirements**

The wiring of the terminal base unit is determined by the current draw through the terminal base. Verify that the current draw does not exceed 10 A.



• Total current draw through the terminal base unit is limited to 10 A. Separate power connections may be necessary.

 Do not daisychain power or ground from the terminal base unit to any AC or DC digital module terminal base unit.

Methods of wiring the terminal base units are shown in Figure 4.

#### Figure 4 - Terminal Base Wiring



### Install the Module

Installation of the FLEX I/O module consists of:

- Mounting the terminal base unit
- Installing the Thermocouple, RTD, and mV module into the terminal base unit
- Installing the connecting wiring to the terminal base unit

If you are installing your module into a terminal base unit that is already installed, proceed to the section, <u>Mount the FLEX I/O Module on the Terminal Base Unit on page 16</u>.

#### **Mount on a DIN Rail**



**ATTENTION:** Do not remove or replace a terminal base unit when power is applied. Interruption of the Flexbus can result in unintended operation or machine motion.

Install the Terminal Base Unit

- 1. Remove the cover plug in the male connector of the unit to which you are connecting this terminal base unit.
- 2. Make sure that the 16 pins in the male connector on the adjacent device are straight and in line so that the mating connector on this terminal base unit mate correctly.



Verify that the female Flexbus connector is fully retracted into the base unit.

3. Position the terminal base at a slight angle and hooked over the top of the 35 x 7.5 mm DIN rail (Allen-Bradley part number 199-DR1; 46277-3).



- 4. Slide the terminal base over tight against the adapter, or proceeding terminal base. Make sure the hook on the terminal base slides under the edge of the adapter, or proceeding terminal base, and the Flexbus connector is fully retracted.
- 5. Rotate the terminal base onto the DIN rail with the top of the rail hooked under the lip on the rear of the terminal base.

Make sure that the female Flexbus connector does not strike any of the pins in the mating connector.

6. Press down on the terminal base unit to lock the terminal base on the DIN rail. If the terminal base does not lock into place, use a screwdriver or similar device to open the locking tab, press down on the terminal base until flush with the DIN rail and release the locking tab to lock the base in place.



Gently push the Flexbus connector into the side of the adapter, or proceeding terminal base, to complete the backplane connection.



For specific wiring information, see the installation instructions for the module you are installing in this terminal base unit.

7. Repeat the above steps to install the next terminal base unit.

Ensure that the cover of the Flexbus connector on the last terminal base unit is in place.

#### **Mount on a Panel or Wall**

Installation of a FLEX system on a wall or panel consists of:

- Laying out the drilling points on the wall or panel
- Drilling the pilot holes for the mounting screws
- Mounting the adapter mounting plate
- Installing the terminal base units and securing them to the wall or panel

If you are installing your module into a terminal base unit that is already installed, proceed to <u>Mount</u> <u>the FLEX I/O Module on the Terminal Base Unit on page 16</u>.

Use the mounting kit Catalog Number 1794-NM1 for panel or wall mounting.



	Description		Description
1	Mounting plate for adapter	3	Terminal base unit (not included)
2	#6 Self-tapping screws	4	Adapter (not included)

To install the mounting plate on a wall or panel:

1. Lay out the required points on the wall or panel as shown in Figure 5.



Figure 5 - Drilling Dimensions for Panel or Wall Mounting

- 2. Drill the necessary holes for the #6 self-tapping mounting screws.
- 3. Mount the mounting plate for the adapter using two #6 self-tapping screws 18 screws are included for mounting up to 8 modules and the adapter.



- 4. Hold the adapter at a slight angle and engage the top of the mounting plate in the indention on the rear of the adapter.
- 5. Press the adapter down flush with the panel until the locking lever locks.
- 6. Position the terminal base unit up against the adapter and push the female bus connector into the adapter.
- 7. Secure to the wall with two #6 self-tapping screws.
- 8. Repeat for each remaining terminal base unit.

#### Mount the FLEX I/O Module on the Terminal Base Unit

The Thermocouple, RTD, and mV input module mounts on a 1794-TB3G or 1794-TB3GS terminal base unit.

1. Rotate keyswitch (3) on terminal base unit (4) clockwise to position 3 as required for the module.

Do not change the position of the keyswitch after wiring the terminal base unit.



	Description		Description
1	Flexbus connector	5	Base unit
2	Latching mechanism	6	Alignment groove
3	Keyswitch	7	Alignment bar
4	Cap plug	8	Module

2. Verify that the Flexbus connector (1) is pushed all the way to the left to connect with the neighboring terminal base or adapter.

You cannot install the module unless the connector is fully extended.

3. Make sure the pins on the bottom of the module are straight so that they align properly with the connector in the terminal base unit.



If you remove or insert the module while the backplane power is on, an electric arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.

- 4. Position the module (8) with its alignment bar (7) aligned with the groove (6) on the terminal base.
- 5. Press firmly and evenly to seat the module in the terminal base unit.

The module is seated when the latching mechanism is locked into the module.

6. Remove the cap plug and attach another terminal base unit to the right of this terminal base unit if necessary.

Make sure that the last terminal base has the cap plug in place.



## **Wiring Information**

Wire the module using a 1794-TB3G, 1794-TB3GK, or 1794-TB3GS terminal base unit.

Figure 6 - 1794-TB3G, 1794-TB3GK, and 1794-TB3GS Wiring



#### **Connect Wiring to the FLEX I/O Module**

Wire the Thermocouple, RTD, and mV module through the terminal base unit on which the module mounts.

The module is compatible with the 1794-TB3G, 1794-TB3GK, and 1794-TB3GS terminal base units.

Connect Wiring Using a 1794-TB3G, 1794-TB3GK, or 1794-TB3GS Terminal Base Unit

- Connect individual signal wiring to numbered terminals on 0...15 row (A), and 17...32 row (B), on the terminal base unit as indicated in <u>Table 2 on page 18</u>. Use a Belden 8761 cable for mV signal wiring, or the appropriate thermocouple wire for your thermocouples.
   Signal wiring shields can be connected to terminals 16 or 33 on row B or terminals 40...45 on
- 2. Connect the +V DC power lead to terminal 34 on row C, terminals 34...51.
- 3. Connect the -V DC common (return-) to terminal 35 on row C, terminals 34...51.



row C.

**ATTENTION:** Do not daisychain power or ground from this terminal base unit to any AC or DC digital module terminal base units.

- If daisychaining power to the next terminal base unit, connect a jumper from terminal 50 (+V DC) on this base unit to the +V terminal on the next terminal base unit.
- 5. Connect a jumper from terminal 51 (-V DC common) to the -V DC common terminal on the next terminal base unit.
- If using cold junction compensators, make these connections as shown in the <u>Table 3 on</u> page 18.

#### **Identify RTD Wire Pairs**

If the RTD wires are color-coded, the wires that are the same color are connected together. If the wires are not color-coded, use an ohmmeter to determine the pairs.

How to Connect a 4-wire RTD

If the 4-wire RTD wires are all different colors, use an ohmmeter to determine which leads are connected together. One of the leads in each pair is the compensation lead. Either lead of the pair can be the compensation lead. Attach one pair to terminals L and -, and the other pair to + and H.



#### How to Connect a 3-wire RTD

If the 3-wire RTD wires are all different colors, use an ohmmeter to determine which leads are connected together. Either lead of the pair can be the compensation lead. Attach one lead of the pair to terminal L, and the other to +. Attach the single lead to -.

#### Table 2 - Wiring Connections for the FLEX I/O Input Module

	Connect the Following:									
Input Types	H	L	+	-	Shield <sup>(1)</sup>					
RTD - 2-wire			1	2						
RTD – 3-wire		3	1	2						
RTD – 4-wire	1a	2a	1	2						
Thermocouple		1		2						
Millivolt		1		2						

(1) Terminals 37, 38 and 39 and 46, 47 and 48 are for cold junction compensation, with 38 and 47 as chassis ground.

#### Table 3 - CJC Sensor Connections

	CJC Sensor			
Input	+	Chassis Ground	-	CJC Tail <sup>(1)</sup>
CJC1	C-37	C-38	C-39	A-5 (B-22)
CJC2	C-46	C-47	C-48	A-12 (B-29)

(1) Terminals 37, 38, and 39, and 46, 47, and 48 are for cold junction compensation, with 38 and 47 as chassis ground. Connect the tail of CJC1 to terminal 5 and CJC2 to terminal 12 if channels 0...3 or 0...7 are configured for thermocouples. Connect the tail of CJC1 to terminal 22 and CJC2 to 29 if channels 4...7 are configured for thermocouples.

#### Table 4 - Terminal Base Unit Wiring Connections

	1794-TB3G, 1794-	TB3GK, and 1794-TB3G	S Terminal Base Units	(1)
RTD or TC Channel	High Signal Terminal (H)	Low Signal Terminal (L)	RTD Source Current (+)	Signal Return (-)
0	A-1	A-2	A-0	A-3
1	A-5	A-6	A-4	A-7
2	A-9	A-10	A-8	A-11
3	A-13	A-14	A-12	A-15
4	B-18	B-19	B-17	B-20
5	B-22	B-23	B-21	B-24
6	B-26	B-27	B-25	B-28
7	B-30	B-31	B-29	B-32
+24V DC Power	34 and 50			<u>.</u>
24V DC Common	35 and 51			

 Terminals 37, 38, and 39, and 46, 47 and 48 are for cold junction compensation. Terminals 16, 33 and 40...45 are chassis ground. Connect the tail of CJC1 to terminal 5 and CJC2 to 12 if channels 0...3 or 0...7 are thermocouples. Connect the tail of CJC1 to terminal 22 and CJC2 to 29 only if channels 4...7 are used.

MPORTANT	<ul> <li>Disconnecting and reconnecting RTDs, Thermocouples, or CJCs with power applied temporarily disturbs the channel steady state data. Allow 2 minutes</li> </ul>
	for settling time after finishing connections
	<ul> <li>If using RTD isolators, use 2- or 4-wire configurations only, and add digital</li> </ul>
	filtering to the inputs.



I



Figure 7 - 2-, 3-, and 4-wire RTD and Thermocouple Wiring to a 1794-TB3G Terminal Base Unit

**ATTENTION:** Keep exposed area of inner conductor as short as possible.





# Notes:

# Configure Your FLEX I/O Module with RSLogix 5000 Software

#### **Overview** This chapter describes how to configure the FLEX I/O Thermocouple, RTD, and mV module for the ControlLogix<sup>®</sup> and CompactLogix<sup>™</sup> system with the Studio 5000 Logix Designer application. The 1794-IRT8 module can communicate through different networks such as ControlNet, Ethernet, PROFIBUS, among others. In the examples below, the Ethernet adapter is used for communication between the Logix processor and the Flexbus. ATTENTION: If using an SLC<sup>™</sup> controller with ControlNet, see the associated I/O scanner documentation. If using a PLC-5<sup>®</sup> controller, see the PLC-5 controller documentation for ControlNet configuration information. You must follow these series of steps to configure your FLEX I/O module in the Studio 5000 Logix Designer. 1. Add and configure the new local bridge, such as 1756-ENBT, to your project. This user manual assumes that you have properly configured this module. See the associated documentation. 2. Add and configure the new adapter, such as a 1794-AENT FLEX I/O EtherNet/IP adapter. This user manual assumes that you have properly configured this module. See the associated documentation. 3. Add and configure your FLEX I/O module as shown in Add and Configure the FLEX I/O Module. 4. Download the configuration to the controller. Add and Configure the In order to add your FLEX I/O Thermocouple, RTD, mV module, you should have added and configured your Ethernet bridge and/or adapter. FLEX I/O Module In the I/O Configuration tree, right-click the 1794-AENT adapter, and select New Module. 1. 🔲 Trends 🗄 ݫ I/O Configuration Right-click the local adapter. 🖻 🖅 1756 Backplane, 1756-A4 1756-L55 ForScreenShots ٩ [1] 1756-ENBT/A LocalEthernetModule Ethernel 1794-AENT/ 🚽 FlexBus New Module. 1756-ENBT/A LocalEthernetM ٩ Cut Ctrl+X Ж. 📴 Сору Ctrl+C R Paste Select New Module. Delete Del Cross Reference Ctrl+E

Properties

Alt+Enter

2. The Select Module dialog appears. Select the FLEX I/O module and select OK.



- 3. Complete the following fields in the New Module dialog that appears. Select OK.
  - Name
  - Description
  - Comm Format
  - Electronic Keying

Type: Vendor:	1794-IRT8 8 Channel Allen-Bradley	24V DC RTD/Then	mocouple Ana	alog Input		
Parent:	AENT					
Name:	irt8_test		Slot 2	-		
Description:	test setup	*				
Comm Format:	Input Data				•	
Revision:	1 1 🛨	Electronic	Keying: Co	mpatible Keying	•	

4. On the Connection tab, specify a value for the Requested Packet Interval (RPI).

Module Properties: AENT: 2	? (1794-IRTB 1.1)	
General Connection* Module Inf	io   Input Configuration	
Bequested Packet Interval (RPI): Inhibit Module Major Fault On Controller If Cor	80.0 📩 ms (2.0 - 750.0 ms)	
← Module Fault		
Status: Offline	OK Cancel	Apply Help

5. Click the Module Info tab to see Module Identification and Status information. These fields are populated when the module goes online.

Module Properties: AENT:2 (1794-IRT8	1.1)
General Connection <sup>®</sup> [Module Info] Input Config Identification Vendor: Product Type: Product Code: Revision:	ration Status Fault: Module Identity:
Status: Offline	Refresh Cancel Apply Help

- 6. Click the Input Configuration tab and specify the values for the following fields:
  - Channel
  - Sensor
  - Sensor Mode
  - Input Filter Cutoff
  - Data Format

Channel			
0-3 4-7		RTD Loop Compensation	,,
	71 1	Channel <u>0</u> :	Ψ.
201601.	I mennocoupie	Channel <u>1</u> :	¥
Sensor <u>T</u> ype:	mV	Channel 2:	+
iensor <u>M</u> ode:	External Compensation	Channel 2	
Detect Faults	on these Channels	Chainer 2	
nput <u>Filter</u> Cutoff:	Hardware Filter Only	Thermocouple Internal Co	mpensation
)ata Format:	10	Reference Junction:	<b>T</b>

#### **Table 5 - Configuration Parameters**

Field Name	Description	Configuration Options	
Sensor	Allows you to select the main sensor function of your module, whether Thermocouple or RTD. You must configure your module based on this main configuration by specifying the next parameters.	<ul><li>Thermocouple</li><li>RTD</li></ul>	
Sensor Type	Allows you to select one of nine thermocouple types or one of eight RTD	For Thermocouple     mV     Type B     Type E     Type J     Type K     Type TXK/XKL(L)     Type N     Type R     Type S     Type T	To help you select the proper operating range of your thermocouple, see <u>Resolution</u> <u>Curves for Thermocouples on</u> <u>page 51</u> .
	types. Default unit is invitor thermocouples and unitis for KTDs.	For RTD • Resistance • 100 Ω Pt 385 • 200 Ω Pt 385 • 100 Ω Pt 3916 • 200 Ω Pt 3916 • 100 Ω Ni 618 • 200 Ω Ni 618 • 120 Ω Ni 672 • 10 Ω Cu 427	To help you specify the value for your RTD, see <u>Sensor Types on</u> <u>page 27</u> .

#### Table 5 - Configuration Parameters (Continued)

Field Name	Description	Configuration Options		
		For Thermocouple <ul> <li>External compensation</li> <li>Internal compensation</li> <li>No compensation</li> <li>Differential compensation</li> </ul>	For a description of the different sensor mode options, for both Thermocouple and RTD, see <u>Table 10 on page 30</u> .	
Sensor Mode	<ul> <li>Allows you to select the operational mode for the thermocouple or RTD inputs.</li> <li>For thermocouple inputs, you can choose the cold junction compensation mode. <ul> <li>Default for thermocouples is external compensation.</li> <li>For RTD inputs, you can choose 2-wire, 2-wire with user-selected RTD offset, 3-wire, and 4-wire.</li> <li>Default for RTD is 2-wire (with no offsets).</li> </ul> </li> </ul>	For RTD • 2-wire compensation (default) • 2-wire with Loop compensation • 3-wire • 4-wire	When you select Internal Compensation for your Thermocouple, you must specify a corresponding Reference Junction value. This parameter sets a fixed reference junction to compensate all thermocouple channels and ranges from 0 °C70 °C. When you select 2-wire with Loop compensation for your RTD, you must specify values for each channel for the RTD Loop Compensation.	
Input Filter Cutoff	Allows you to select one of eight levels on input filtering. The module microprocessor accomplishes the single pole, low-pass filtering. The filter selections range from Hardware Only to 5 s time constant. The times are approximate because they are based on the module scan time, which varies. The default is Hardware Only.	<ul> <li>Hardware Filter Only (default)</li> <li>25 ms</li> <li>100 ms</li> <li>250 ms</li> <li>500 ms</li> <li>1 s</li> <li>2 s</li> <li>5 s</li> </ul>		
Data Format	Allows you to specify the format of the data reported. Module defaults to -4000+10000 in millivolt mode, and 05000 in $\Omega$ mode with implied decimal points (that is -40.00 mV, 0.1 $\Omega$ ) whenever °C, °F, °K is selected.	• °C • °F • °K • -32767+32767 • 065535		

7. After you have completed all Module Configuration parameters, click OK in the Module Properties dialog box.

The FLEX I/O module shows in the I/O Configuration tree.



To be able to check if your configured parameters are acceptable and the configuration is successful, you must go online.

See the Studio 5000 Logix Designer Online Help for detailed descriptions of the configuration parameters.

# Read and Write Configuration Maps for the FLEX I/O Module

## **Overview**

## **Configure Your Input Module**

This chapter describes how to configure, read data from, and map data to your FLEX I/O Thermocouple, RTD, and mV Input module.

The Thermocouple, RTD, and mV input module is configured using a group of data table words that are mapped by the processor that is used when the connection to the module is established.

The software configurable features available are:

- Input range selection
- Selectable single pole low pass filter
- Data reported in °F, °C, °K, mV, Ω, unipolar or bipolar count
- Fault detection

## Configurable Options and Their Effect on the Channels

There are two types of configurable options: those that affect all channels, and those that affect each group of four input channels.

#### **Options that Affect All Channels**

#### Input Filter Selection

This combination of bits allows you to select one of eight levels on input filtering. The module microprocessor accomplishes the single pole, low pass filtering. The filter selections range from Hardware Only to 5 s time constant. The times are approximate because they are based on the module scan time, which varies. The default is Hardware Only.

#### Data Format Selection

This set of bits allows you to select one of these five formats:

- Degree C
- Degree F
- Degree K
- Unipolar The endpoints for Unipolar are scaled to the endpoints of the thermocouple or RTD range. The default unit is mV.
- Bipolar The endpoints for Bipolar are scaled to the endpoints of the thermocouple or RTD range. It uses Ω as the default unit.

#### **Options that Affect Each Group of Four Inputs**

#### Sensor Type

This set of bits allows you to select one of nine thermocouple types or one of eight RTD types. Default unit is mV for thermocouples and ohms for RTDs.

#### Sensor Mode

This set of bits allows you to select the operational mode for the thermocouple or RTD inputs. For thermocouple inputs, you can choose the cold junction compensation mode: internal, external, no CJC and differential measurement between two channels, for example, the value of channel 0 minus the value of channel 1 appears in the channel 0 and channel 1 data table locations. For RTD inputs, you can choose 2-wire, 2-wire with user-selected RTD offset, 3-wire, and 4-wire. Default for thermocouples is external CJC; default for RTDs is 2-wire (with no offsets).

#### Input Types

This set of bits allows you to select one of two input types: thermocouple (millivolt) or RTD (resistance). The default input type is thermocouple.

#### **Reference Junction**

These bits allow you to select from seven fixed temperatures for the CJC value that is used by the module in thermocouple mode. Use this mode when the ambient temperature surrounding the thermocouple connection point is known and steady. The default temperature is 0  $^{\circ}$ C (32  $^{\circ}$ F).

#### Fault Mode

You can enable or disable the fault detection. When enabled in thermocouple mode, each channel is monitored for an open circuit. If an open is detected, the overrange and fault bits are set for that channel, and the channel data is set to the maximum value (Series A), or minimum value (Series B) for the chosen mode of operation.

When enabled in RTD mode, each channel is monitored for an open circuit (RTD and wires) and short circuits (RTD). If an open is detected, the overrange and fault bits are set for that channel, and the channel data is set to the maximum value for the chosen mode of operation. If a short is detected, the underrange bit is set for that channel, except when in  $\Omega$  mode. The channel data is set to the minimum value for the chosen mode of operation.

#### RTD Offset

You can select from four fixed resistive values that are used by the module when inputs are configured for 2-wire with user-selected RTD offset. The RTD offset is used to nullify the effects of the resistance of long lead wires. Each value represents the total resistance of both leads of a 2-wire RTD. For example, if you choose 5  $\Omega$ , the module compensates for a total of 5  $\Omega$  of lead resistance.

You can perform a calibration operation that measures the actual total lead resistance with RTD replaced with a short circuit. The value that is stored from this operation is used when the option Use Channel Loop Compensation Value is selected. This is also the default setting and is initially set to 0 at the factory. Each channel has its own pair of RTD offset bits and a Channel Loop Compensation value.

## **Sensor Types**

Individual input channels are configurable to operate with the following sensor types:

Table 6 - Sensor Types

RTD Type	Thermocouple Type
Sensor type for channels 03	Sensor type for channels 03
Sensor type for channels 47	Sensor type for channels 47
Resistance (default)	mV (default)
100 Ω Pt $\alpha$ = 0.00385 Euro (-200+870 °C) (-328+1598 °F)	B 3001800 °C (5723272 °F)
200 Ω Pt $\alpha$ = 0.00385 Euro (-200+400 °C) (-328+752 °F)	E -270+1000 °C (-454+1832 °F)
100 Ω Pt $\alpha$ = 0.003916 U.S. (-200+630 °C) (-328+1166 °F)	J -210+1200 °C (-346+2192 °F)
200 Ω Pt $\alpha$ = 0.003916 U.S. (-200+400 °C) (-328+752 °F)	K -270+1372 °C (-454+2502 °F)
100 Ω Nickel $\alpha$ = 0.00618 (-60+250 °C) (-76+482 °F)	TXK/XK(L) -200+800 °C (-328+1472 °F)
200 Ω Nickel $\alpha$ = 0.00618 (-60+200 °C) (-76+392 °F)	N -270+1300 °C (-450+2372 °F)
120 $\Omega$ Nickel $\alpha$ = 0.00672 (-80+320 °C) (-112+608 °F)	R -50+1768 °C (-58+3214 °F)
10 Ω Copper $\alpha$ = 0.00427 (-200+260 °C) (-328+500 °F)	S -50+1768 °C (-58+3214 °F)
	T -270+400 °C (-454+752 °F)

Select individual channel ranges using write word 1 of the block-transfer write instruction.

# • Disconnect

- Disconnecting and reconnecting RTDs with power applied temporarily disturbs the steady state data of the channel. Allow 2 minutes for settling time or cycle power to the module after terminating connections.
- If using RTD isolators, we recommend using 2- or 4-wire configurations only and digital filtering to the inputs.
- The range -32,768...+32,767 should only be used with mV selection. Signals from a thermocouple or RTD are non-linear, the mV selection is not recommended for thermocouple or RTD real-time readings. If selected, the module returns the mV generated by the thermocouple or RTD, in addition to any offsets generated by wiring without any correction for the non-linearity of the device.
  When the module is configured for mV the CJC compensation is not applied for thermocouple devices. For thermocouples and RTDs you should use F or C data format. When configured

as thermocouple or RTD the module uses an internal table to adjust for the nonlinear mV returned by the field devices. After the internal calculations are performed the module provides results in degrees F or C.

## **Read Data From the Module**

Read programming transmits status and data from the TC and RTD input module to the processor data table in one I/O scan. The processor user program initiates the request to transfer data from the TC and RTD input module to the processor.

# Map Data for the Module

The following read and write words and bit/word descriptions describe the information that is written to and read from the TC and RTD input module. The module uses up to 11 words of input data and up to 4 words of output data. Each word is composed of 16 bits.

#### Figure 9 - Thermocouple and RTD Input Module Image Table Mapping



#### **Block-transfer Read and Write**

The following block-transfer read and write word bit information is presented for experienced users only.

#### Table 7 - Input Map (Block-transfer Read)

Dec.	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Oct.	17	16	15	14	13	12	11	10	07	06	05	04	03	02	01	00
Word O	Channel	0 Input D	ata													
Word 1	Channel	1 Input Da	ata													
Word 2	Channel	2 Input D	ata													
Word 3	Channel 3 Input Data															
Word 4	Channel	4 Input D	ata													
Word 5	Channel 5 Input Data															
Word 6	Channel	6 Input D	ata													
Word 7	Channel	7 Input D	ata													
Word 8	Overrang	je Alarm	Bits (chai	nnel 0 = t	oit 8, and	so on.)			Underrar	nge Alarm	Bits (char	nnel 0 = b	oit O, and so	on.)		
Word 9	CH 7 Fit	CH 6 Flt	CH 5 Flt	CH 4 Flt	CH 3 Flt	CH 2 Fit	CH 1 Flt	CH O Flt	Res	CJC2 Alm	CJC1 Alm	SAB	CJC Status	Reserved		
Word 10	Resp Flag	Comma	nd Respo	nse					Respons	e Data						
Where:	CH Flt = 0 CJC = Co SAB = Se Alm = Ala	Channel I Id Juncti ries of ur arm	Fault on Comp hit; 0 = Se	ensation eries A, 1 :	= Series	В										

Dec.	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Oct.	17	16	15	14	13	12	11	10	07	06	05	04	03	02	01	00
Word O	Reserve	d			Data Format		Data Format		Flt Mode CH 47	Flt Mode CH 03	Reference Junction		1	Filter Cutoff		
Word 1	TC/RTD CH 47		Sensor I CH 47	1ode	Sensor 1 CH 47	Гуре			TC/RTD CH 03		Sensor Mode Sensor 1 CH 03 CH 03		уре			
Word 2	RTD Offs CH 7	et	RTD Offs CH 6	et	RTD Offset RTD Offset CH 5 CH 4				RTD Offset CH 3		RTD Offse CH 2	et	RTD Offse CH 1	et	RTD Offs CH O	et
Word 3	Cmd Flag EDT Command							EDT Command Data								
Where:	Flt = Fau CH = Cha TC/RTD = EDT = Ex	Fit = Fault CH = Channel TC/RTD = Thermocouple/Resistance Temperature Detector EDT = Extended Data Transfer														

#### Table 8 - Output Map (Block-transfer Write)

Table 9 - Bit/Word Descriptions for the Input Module Block Transfer Read Words

Word	Dec. Bits (Octal Bits)	Desc	ription							
Read Word O	0015 (0017)	Chan	nel O Inp	ut data	3					
Read Word 1	0015 (0017)	Chan	nel 1 Inp							
Read Word 2	0015 (0017)	Chan	Channel 2 Input data							
Read Word 3	0015 (0017)	Channel 3 Input data								
Read Word 4	0015 (0017)	Chan	Channel 4 Input data							
Read Word 5	0015 (0017)	Chan	nel 5 Inp	ut data	1					
Read Word 6	0015 (0017)	Chan	Channel 6 Input data							
Read Word 7	0015 (0017)	Chan	Channel 7 Input data							
	0007	<b>Underrange Bits</b> – These bits are set if the input signal is below the minimum range of the input channel. Bit 00 corresponds to channel 0bit 07 corresponds to channel 7.								
Read Word 8	0815 (1017)	Over maxi Bit 08 and s	<b>Overrange Bits</b> – These bits are set if 1), the input signal is above the maximum range of the input channel; or 2), an input is disconnected. Bit 08 (10) corresponds to channel 0, bit 09 (11) corresponds to channel and so on.							
		<b>Diagnostic Bits</b> – Represent module configuration and/or hardware errors.								
		Bit	03	02	01	00				
	00.07		0	0	0	0	Reserved for factory use			
	0003		0	0	1	0	Improper module configuration			
			0	1	1	0	RAM fault			
			0	1	1	1	EEPROM fault			
			0001, 0100, and 00111111 Reserved for factory use							
Read Word 9	04	Series of Unit (SAB) – O = Series A, 1 = Series B								
	0506	<b>Cold Junction Compensation Fault Bits</b> – These bits are set (1) when the corresponding cold junction compensator lead is broken, unattached, or shorted, and the thermocouple is set to "external compensation." Bit 05 corresponds to CJC1, and bit 06 to CJC2.								
	07	Not u	ised							
	0815 (1017)	Fault open maxi chan	t <b>Alarm</b> I s (brokei mum val nel 1, and	<b>Bits</b> – <i>F</i> n, disco ue. Bit d so on	An alarm onnected) 08 (10) co	bit is se ). If the a prrespo	et (1) when an individual input lead alarm is enabled, the channel reads nds to input channel 0, bit 09 (11) to			

Word	Dec. Bits (Octal Bits)	Description
	0007	<b>Extended Data Table Data Response Bits</b> - These bits echo the EDT command data written to the module during calibration.
Read Word 10	0814 (1016)	<b>Extended Data Table Command Response Bits</b> – These bits echo the EDT command written to the module during calibration.
	15 (17)	Reserved for factory use

#### Table 10 - Bit/Word Descriptions for Block-transfer Write Words

Word	Dec. Bits (Octal Bits)	Descri	ption										
		Input F	ilter Se	lection	bits								
		Bit	02	01	00	Filter Ti	me Constants - Actual filtering depends on the module mode of operation						
			0	0	0	Hardwar	e filtering only (default filtering)						
			0	0	1	25 ms							
	00 02		0	1	0	100 ms							
	0002		0	1	1	250 ms							
			1	0	0	500 ms							
			1	0	1	1s							
			1	1	0	2 \$							
			1	1	1	5 s							
		Referer referer	<b>ence Ju</b> nce juno	<b>inctio</b> ction to	<b>n</b> - Use o comp	ed when ir ensate all	put type is set to thermocouple and sensor mode is set to internal compensation. Sets a fixed thermocouple channels.						
		Bit	05	04	03	Referen	ence Junction						
			0	0	0	0 °C (32 °F)							
	Bits 0305		0	0	1	20 °C (68	) °F)						
			0	1	0	25 °C (77	°F)						
Write Word ()			0	1	1	30 °C (86 °F)							
			1	0	0	40 °C (104 °F)							
			1	0	1	50 °C (122 °F)							
			1	1	0	60 °C (14	0 °F)						
			1	1	1	70 °C (15	8 °F)						
	Bits 0607	Fault Mode Bits – When a bit is set (1), fault mode is enabled for that channel. Bit 06 corresponds to channels 03; bit 07 corresponds to channels 47. 0 = Disabled 1 = Enable wire-off detection											
	Bits 0811 (1013)	Data format – Module defaults to -4000+10000 in millivolt mode, and 05000 in Ω mode with implied decimal points ( -40.00+40.00 mV, 0.1 Ω) whenever °C, °F, °K is selected.											
		Bit	11	10	09	08	Data type for channels 07						
			0	0	0	0	°C (implied decimal point xxxx.x)						
			0	0	0	1	°F (implied decimal point xxxx.x)						
	Bits 0811 (1013)		0	0	1	0	°K (implied decimal point xxxx.x)						
			0	0	1	1	-32767+32767						
			0	1	0	0	065535						
			0101	.1111 no	t used								
	Bits 1215 (1417)	Not us	ed										

Word	Dec. Bits (Octal Bits)	Descri	ption									
		Sensor	Туре	(Ther	mocol	uple or RT	D)					
		RTD Type										
		Bit	03	02	01	00	Sensor Type for Channels 03					
			0	0	0	0	Resistance (default)					
			0	0	0	1	100 Ω Pt $\alpha$ = 0.00385 Euro (-200+870 °C) (-328+1598 °F)					
			0	0	1	0	200 Ω Pt α = 0.00385 Euro (-200+400 °C) (-328+752 °F)					
			0	0	1	1	100 Ω Pt $\alpha$ = 0.003916 U.S. (-200+630 °C) (-328+1166 °F)					
			0	1	0	0	200 Ω Pt α = 0.003916 U.S. (-200+400 °C) (-328+752 °F)					
			0	1	0	1	100 Ω Nickel (-60+250 °C) (-76+482 °F)					
			0	1	1	0	200 Ω Nickel (-60+200 °C) (-76+392 °F)					
			0	1	1	1	120 Ω Nickel (-80+320 °C) °F) (-112+608 °F)					
			1	0	0	0	10 Ω Copper (-200+260 °C) °F) (-328+500 °F)					
			1001	1111 no	t used							
	DIIS 0000	Therm	ocoupl	е Тур	e							
		Bit	Bit 03 02 01 00 Sensor Type for Channels 03		00	Sensor Type for Channels 03						
			0	0	0	0	mV (default)					
			0	0	0	1	B 3001800 °C (5723272 °F)					
			0	0	1	0	E -270+1000 °C (-454+1832 °F)					
			0	0	1	1	J -210+1200 °C (-346+2192 °F)					
			0	1	0	0	K -270+1372 °C (-454+2502 °F)					
			0	1	0	1	TXK/XK(L) -200+800 °C (-328+1472 °F)					
			0	1	1	0	N -270+1300 °C (-450+2372 °F)					
Write Word 1			0	1	1	1	R -50+1768 °C (-58+3214 °F)					
			1	0	0	0	S -50+1768 °C (-58+3214 °F)					
			1	0	0	1	T -270+400 °C (-454+752 °F)					
			1010	1111 no	t used							
		Sensor	<sup>·</sup> Mode	Selec	t bits							
	Bits 0405	Bit	05	04	Sens	or Mode S	Select for Channels 03					
		Therm	ocoupl	e								
			0	0	Exte comp	r <b>nal Comp</b> pensation i	<b>Densation</b> – Uses cold junction sensors. Both CJC sensors must be used when external s selected.					
			0	1	Inter	nal Comp	ensation - Uses the user-selected Reference Junction Selection.					
			1	0	No co	ompensatio	on. Data is referenced to 0 °C (32 °F).					
			1	1	Differ	rential mea	asurement between 2 channels (01, 23, 45, 67)					
		RTD										
			0	0	2-wir	e RTD no c	compensation					
			0	1	2-wire RTD with user-selected RTD offset							
			1	0	3-wir	re RTD						
			1	1	4-wir	re RTD						
		Input T	'ype Se	elect	1.							
			07	06	Input	type selec	ction for channels 03					
	Bits 0607		0	0	Therr	nocouple						
		Bit	0	1	RTD							
			1	U	Not u	ised						
			I	I	Not u	ised						

Table 10 - Bit/Word Descriptions for Block-tran	nsfer Write Words (Continued)
---	-------------------------------

Word	Dec. Bits (Octal Bits)	Descr	iption										
		Senso	r Type	(Ther	moco	uple or R1	TD)						
		RTD Type											
		Bit	11	Sensor Type for Channels 47									
			0	0	0	0	Resistance (default)						
			0	0	0	1	100 Ω Pt $\alpha$ = 0.00385 Euro -200+870 °C (-328+1598 °F)						
	Di. 00 11		0	0	1	0	200 Ω Pt α = 0.00385 Euro -200+400 °C (-328+752 °F)						
	Bits 0811 (1013)		0	0	1	1	100 Ω Pt $\alpha$ = 0.003916 U.S200+630 °C (-328+1166 °F)						
	(100)		0	1	0	0	$200 \Omega \text{Pt}\alpha = 0.003916 \text{U.S.} -200+400 ^\circ\text{C} (-328+752 ^\circ\text{F})$						
			0	1	0	1	100 Ω Nickel -60+250 °C (-76+482 °F)						
			0	1	1	0	200 Ω Nickel -60+200 °C (-76+362 °F)						
			0	1	1	1	120 Ω Nickel -80+320 °C (-112+608 °F)						
			1	0	0	0	10 Ω Copper -200+260 °С (-328+470 °F)						
			1001	.1111 no	ot used	1							
		Therm	nocoup	le Typ	e								
		Bit	11	10	09	08	Sensor Type for Channels 47						
			0	0	0	0	mV (default)						
			0	0	0	1	B 3001800 °C (5723272 °F)						
	Bits 0811 (1013)		0	0	1	0	E -270+1000 °C (-454+1832 °F)						
			0	0	1	1	J -210+1200 °C (-346+2192 °F)						
			0	1	0	0	K -270+1372 °C (-454+2502 °F)						
			0	1	0	1	TXK/XK(L) -200+800 °C (-328+1472 °F)						
Write Word 1			0	1	1	0	N -270+1300 °C (-450+2372 °F)						
(continued)			0	1	1	1	R -50+1768 °C (-58+3214 °F)						
			1	0	0	0	S -50+1768 °C (-58+3214 °F)						
			1	0	0	1	T -270+400 °C (-454+752 °F)						
		10101111 not used											
		Sensor Mode Select bits											
		Bit	13	12	Sens	or Mode S	Select for Channels 47						
		Therm	nocoup	le	-								
			0	0	<b>External Compensation</b> - Uses cold junction sensors. Both CJC sensors must be used when external compensation is selected.								
			0	1	Inter	rnal Comp	nensation – Uses the user-selected Reference Junction.						
	Bits 1213 (14 15)		1	0	No co	ompensati	ion. Data is referenced to 0 °C (32 °F).						
	(11.1.10)		1	1	Diffe	rential me	asurement between 2 channels.						
		RTD											
			0	0	2-wir	re RTD no (	compensation						
			0	1	2-wir	re RTD with	n user-selected offset						
			1	0	3-wi	re RTD							
			1	1	4-wi	re RTD							
		Input Type Select											
		Bit	15	14	Inpu	t Type Se	lection for Channels 47						
	Bits 1415		0	0	Ther	mocouple							
	(1617)		0	1	RTD								
			1	0	Not u	ised							
			1	1	Not u	ised							

#### Table 10 - Bit/Word Descriptions for Block-transfer Write Words (Continued)

Word	Dec. Bits (Octal Bits)	Descri	escription								
		<b>RTD Offset Select Bits</b> – used when input type is set to RTD and sensor mode select is set to 2-wire with user-selected RTD offset. Allows you to set the type of RTD loop resistance compensation that is used for all RTDs or one of three fixed values for all channels. <b>NOTE:</b> Not applicable to 10 Ω copper RTD.									
		Bit	01	00	RTD Offset Select Bits - Channel O						
			03	02	RTD Offset Select Bits - Channel 1						
			05	04	RTD Offset Select Bits - Channel 2						
			07	06	RTD Offset Select Bits - Channel 3						
Write Word 2	0015 (0017)		09	80	RTD Offset Select Bits - Channel 4						
			11		RTD Offset Select Bits - Channel 5						
			13	12	RTD Offset Select Bits – Channel 6						
			15	14	RTD Offset Select Bits - Channel 7						
			0	0	Use channel loop compensation value stored during calibration procedure for 2-wire RTD (default = 0 $\Omega$ ).						
			0	1	5 Ω (total lead resistance)						
			1	0	10 Ω (total lead resistance)						
			1	1	15 D						
	0007	<b>Extenc</b> genera	<b>led Da</b> I chanr	<b>ta Tab</b> nel cali	<b>le Data Bits</b> – These bits are written to the module during calibration. They are used to define offset, gain, and bration.						
Write Word 3	0814 (1016)	<b>Extended Data Table Command Bits</b> – These bits are written to the module during calibration. They are used to select char calibration action.									
	15 (17)	Reserv	ed for t	factory	use only						

#### Table 10 - Bit/Word Descriptions for Block-transfer Write Words (Continued)

# Series A Functionality in a Series B Module

To employ Series A functionality when using a Series B 1794-IRT8 module, connect a wire from terminal 39 to terminal 48 on the 1794-TB3G or 1794-TB3GS terminal base unit. When terminals 39 and 48 are wired together, bit 4 in Read Word 9 are **not** set (0), indicating that the module is in Series A functionality.



**ATTENTION:** If these terminals are not connected together, the Series B product defaults to Series B functionality.

# Notes:

# **Calibrate Your Module**

#### **Overview**

## When and How to Calibrate Your FLEX I/O Module

This chapter explains the tools, equipment, and procedure for calibrating your FLEX I/O Thermocouple, RTD, and mV input module.

This module is shipped to you already calibrated. If a calibration check is required, the module must be in a FLEX system. We recommend recalibrating your module, if the module is going to be used in an environment with temperature other than 25  $^{\circ}$ C (77  $^{\circ}$ F) and 30% humidity.



**ATTENTION:** Perform module calibration periodically, based on your application, or at least once a year. Module calibration may also be required to remove module error caused by aging components in your system. Offset calibration must be done first, followed by gain calibration.

**IMPORTANT** You must use a 1794-TB3G or 1794-TB3GS terminal base when calibrating this module.

Calibration can be accomplished using the manual calibration procedure described in the following sections.

## **Tools and Equipment**

To calibrate your Thermocouple, RTD, and mV input module, you need the following tools and equipment:

Tool or Equipment	Description	
Precision Resistors	High Precision Resistors: 383 W, 0.01%, 5ppm/°C 100 W, 0.01%, 5ppm/°C 10 KΩ, 0.5%, 5ppm/°C	
Precision Voltage Source	320 mV, 1 μV resolution	Analogic 3100, Data Precision 8200 or equivalent
Industrial Terminal and Interconnect Cable	Programming terminal for Allen-Bra	adley family processors

## **Calibrate Your Input Module**



**ATTENTION:** You must calibrate the module in a FLEX system. The module must communicate with the processor and an industrial terminal. You can calibrate input channels in any order, or all at once.

**IMPORTANT** To allow the internal module temperature to stabilize, apply power to the module at least 20 minutes before calibration.

When using remote I/O, before calibrating your module, you must enter ladder logic into the processor memory, so that you can initiate block-transfer writes (BTW) to the module, and read inputs (BTR) from the module.

To calibrate the module manually:

- 1. Apply a reference to the desired inputs.
- 2. Send a message to the module to indicate which inputs to read and what calibration step is being performed (offset).

The module returns a response which echoes the message sent to the module. The module stores this input data.

- 3. Apply a second reference signal to the module.
- 4. Send a second message to indicate which inputs to read and what calibration step is being performed (gain).

The module computes the new calibration values for the inputs and returns a response which echoes back the message sent to the module. If the calibration cannot be completed, the module returns a fault message.

#### **Calibration Setup**



Connect + to terminals 2, 6, 10, 14, 19, 23, 27, and 31

Connect - to terminals 3, 7, 11, 15, 20, 24, 28 and 32

Connect one 10 k $\Omega$ , 0.5% resistor across terminals 37 and 39 and another across 46 and 48.

|--|

Type of Input	Connect the Following:											
	Н	L	+	-	Shield							
RTD – 4-wire	1a	2a	1	2								
Millivolt		1		2								









RTD or	1794-TB3G and 1794-TB3GS Terminal Base Units <sup>(1)</sup>										
Channel	High Signal Terminal (H)	Low Signal Terminal (L)	RTD Source Current (+)	Signal Return (-)							
6	26	27	25	28							
7	30	31	29	32							
24V DC Power	34 and 50	·									
24V DC Common	35 and 51										

Table 12 - Wiring to the 1794-TB3G and 1794-TB3GS Terminal Base Units (Continued)

(1) Terminals 16, 33, and 40...45 are chassis ground.

## **Read and Write Words for Calibration**

Table 13 and Table 14 provide read and write words for module calibration.

#### Table 13 - Write Words for Calibration

Decimal	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Octal	17	16	15	14	13	12	11	10	07	06	05	04	03	02	01	00
Word	Write															
0	Reserve	rved Data Format				Flt Mode CH 03	Flt Mode CH 47	Reference Junction Filter Select								
1	TC/RTD	Ch. 47	Sensor CH 47	Mode	Sensor	Sensor Type CH 47			TC/RTD Ch	. 03	Sensor Mo CH O3	de	Sensor Type CH 03			
2	RTD Offs	set CH 7	RTD Off:	set CH 6	RTD Offs	RTD Offset CH 5 RTD Offset CH 4			RTD Offset CH 3		RTD Offset RTD Offset RTD Offset CH 2 CH 1 CH 0					
3	EDT command						EDT command data									
Where:	Flt = Fault TC/RTD = Thermocouple/Resistance Temperature Detector EDT = Extended Data Transfer															

#### Table 14 - Read Words for Calibration

Decimal	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Octal	17	16	15	14	13	12	11	10	07	06	05	04	03	02	01	00
Word	Read															
0	Channel O Input Data															
1	Channel 1 Input Data															
2	Channe	el 2 Input	Data													
3	Channel 3 Input Data															
4	Channe	el 4 Input	Data													
5	Channe	el 5 Input	Data													
6	Channe	el 6 Input	Data													
7	Channe	el 7 Input I	Data													
8	Overra	nge Alarm	ı Bits (cha	annel 0 =	bit 08, aı	nd so on.	)		Underrang	je Alarm Bit	ts (channel	0 = bit 00,	and so on.)			
9	Ch7 Flt	Ch6 Flt	Ch5 Flt	Ch4 Flt	Ch3 Flt	Ch2 Flt	Ch1 Flt	ChO Flt		CJC 2 Flt	CJC 1 Flt	SAB	Diagnostic	: Status		
10	EDT command response EDT data response															
Where:	Flt = Fault CJC = Cold Junction Compensation SAB = Series of unit; 0 = Series A; 1 = Series B															



**ATTENTION:** The CJC Status bit, Read Word 9, Bit 3 is added with Firmware C release of the 1794-IRT8 Series B module.

- The CJC Status bit is turned On when the temperature between the CJC is greater than 6  $^\circ\text{C}$  but less than 12  $^\circ\text{C}$  .
- When this temperature difference is above 12 °C, then the CJC Alarm bits are set.
- If a CJC temperature is overrange or underrange, then the associated CJC Alarm
- bit is set. In this condition, the CJC Status bit is not set. • The CJC Status bit does not exist in Series A.

Config Word 3 EDT Command Bits 815	Meaning	Config Word 3 Bits 47	Config Word 3 Bits 03	Meaning
Dec. (Hex)		Channel No.	Command data	
	General calibration by channel	07	1	Channel internal current source and current sense resistor, with 4-wire external 383 $\Omega$ inputs.
4 (4)		07	2	Channel internal current source and current sense resistor with 4-wire external 100 $\boldsymbol{\Omega}$ inputs.
		07	3	Loop channel compensation for 2-wire RTD
		07	4	CJC calibration
	Offset calibration by channel	07	0	Gain= 1, input = -320 mV
		07	1	Gain = 2, input = 0.0 mV
Б (Б)		07	2	Gain = 4, input = -50 mV
5 (5)		07	3	Gain = 8, input = -10.0 mV
		07	4	Gain = 16, input = -9 mV
		07	5	Gain = 32, input = 1.0 mV
	Gain calibration by channel		0	Gain = 1, input = 320 mV
			1	Gain = 2, input = 320 mV
6 (6)			2	Gain = 4, input = 110 mV
0 (0)			3	Gain = 8, input = 70 mV
			4	Gain = 16, input = 29 mV
			5	Gain = 32, input = 19 mV
	Calibration all channels			
	General calibration all channels	0	1	Channel internal current source and current sense resistor, with 4-wire external 383 $\Omega$ inputs.
36 (24)		0	2	Channel internal current source and current sense resistor with 4-wire external 100 $\boldsymbol{\Omega}$ inputs.
		0	3	Loop channel compensation for 2-wire RTD
		0	4	CJC calibration
	Offset calibration all channels	1	0	Gain = 1, input = -320 mV
		1	1	Gain = 2, input = 0.0 mV
		1	2	Gain = 4, input = -50 mV
		1	3	Gain = 8, input = -10.0 mV
		1	4	Gain = 16, input = -9 mV
		1	5	Gain = 32, input = 1.0 mV
	Gain calibration all channels	2	0	Gain = 1, input = 320 mV
		2		Gain = 2, input = 320 mV
		2		Gain = 4, input = 110 mV
		2		Gain = 8, input = 70 mV
		2		Gain = 16, input = 29 mV
		2		Gain = 32, input = 19 mV

#### Table 15 - EDT Calibration Command and Command Data Summary

#### **Offset Calibration**

Inputs can be calibrated one at a time or simultaneously. To calibrate the offsets, proceed as follows:

- 1. Apply power to the module for 20 minutes before calibrating.
- Connect a precision millivolt source across each input channel. Set the source to -320.00 mV for a gain of 1. Connect all (L) signal terminals together and attach to the positive lead from the precision voltage source. Connect all (-) signal terminals together and attach to the negative lead.

		All Cha	nnels	Single Channel		
		EDT Command		EDT Command Dec. or Hex	EDT Command Data Dec. or Hex	
<b>Gain Selected</b>	Input (mV)	Hex	Decimal	Bits 815	Bits 47	Bits 03
1	-320.00 + 0.064 mV	2410	9232	05	07	0
2	0.000 + 0.032 mV	2411	9233	05	07	1
4	-50.00 + 0.016 mV	2412	9234	05	07	2
8	-10.00 + 0.008 mV	2413	9235	05	07	3
16	-9.00 + 0.004 mV	2414	9236	05	07	4
32	1.000 + 0.002 mV	2415	9237	05	07	5

- Initiate a write to the module with the appropriate value in the EDT command location (Write Word 3, bits 00...15), as shown in <u>Table 16</u>.
- 4. Monitor the EDT response location (Read Word 11 bits 00...15) for an echo of the EDT command. Depending on which command you sent, it should show 241X Hex.

If the EDT response word reads 80FF (Hex), repeat step 3. Make sure that you allow sufficient time for the module to respond to your request. If there is no change, calibration has failed. Check the wiring and try again.

- 5. Set the precision millivolt source to the value required for a gain of 2. Repeat steps 3 and 4 for gain 2. Repeat for each gain setting.
- 6. When all offset calibrations are successful, proceed to Gain Calibration.

#### **Gain Calibration**

After completing the offset calibration, proceed with the gain calibration.

 Connect a precision millivolt source across each input channel. Set the source to 320.00 mV for a gain of 1. Connect all (L) signal terminals together and attach to the positive lead from the precision voltage source. Connect all (-) signal terminals together and attach to the negative lead.

#### Table 17 - EDT Commands for Gain Calibration

		All Chan	nels	Single Channel	annel			
		EDT Con	nmand	EDT Command Dec. or Hex	EDT Comm Dec. or He	: Command Data :. or Hex		
<b>Gain Selected</b>	Input (mV)	Hex	Decimal	Bits 815	Bits 47	Bits 03		
1	-320.00 + 0.064 mV	2420	9248	06	07	0		
2	320.00 + 0.032 mV	2421	9249	06	07	1		
4	110 + 0.016 mV	2422	9250	06	07	2		
8	70.00 + 0.008 mV	2423	9251	06	07	3		
16	29.00 + 0.004 mV	2424	9252	06	07	4		
32	19.00 + 0.002 mV	2425	9253	06	07	5		

- 2. Apply power to the module for 20 minutes before calibrating.
- 3. After the connections stabilize, initiate a Write Word with the appropriate EDT command location (Write Word 3, bits 00...15) as shown in <u>Table 17</u>.

4. Monitor the value in the EDT response location (Read Word 11, bits 00...15) for an echo of the EDT command. Depending on which command you sent, it should show 242X Hex.

If the EDT response word reads 80FF (Hex), repeat step 3. Make sure that you allow sufficient time for the module to respond to your request. If there is no change, calibration has failed. Check the wiring and try again.

5. Set the precision millivolt source to the value required for a gain of 2. Repeat steps 3 and 4 for gain 2. Repeat for each gain setting.

When all gain calibrations are successful, proceed to perform <u>Current Source Calibration</u>.

#### **Current Source Calibration**

The current sources can be calibrated one at a time or all at once. To calibrate all current sources, proceed as follows:

- 1. Connect a 383 Ω, 0.01% resistor across (H, +) and (L, -) of each input channel (8 resistors).
- 2. Apply power to the module for 20 minutes before calibrating.
- Initiate a write to the module with a 2401 (Hex) value in EDT command location (Write Word 3, bits 00...15), as shown, for calibrating all channels at once. For individual channel calibrations, use the 04X1 (Hex) (0401, 0411, 0421...0471 Hex).
- 4. Monitor the EDT response location (Read Word 10, bits 00...15) for an echo of the EDT command.
- 5. If the EDT response word reads 80FF (Hex), repeat step 3. Make sure that you allow sufficient time for the module to respond to your request. If there is no change, calibration has failed. Check the wiring and try again.
- Connect a 100 Ω, 0.01% resistor across (H, +) and (L, -) of each input channel (8 resistors). Repeat steps 3 and 4 using the EDT command value of 2402 (Hex) for calibrating all channels at once. For individual channel calibrations, use the 04X2 (Hex) (0402, 0412, 0422...0472 Hex).

When all calibrations are successful, proceed to the Cold Junction Calibration.

#### **Cold Junction Calibration**

Both cold junction compensation inputs must be calibrated at the same times. To calibrate both simultaneously, proceed as follows:

- 1. Connect 10 K0, 0.5% resistors across terminals 37 and 39 (CJC 1) and terminals 46 and 48 (CJC 2).
- 2. Apply power to the module for 20 minutes before calibrating.
- 3. Initiate a write to the module with a 2404 (Hex) value in the EDT command location (Write Word 3, bits 00...15).
- Monitor the EDT response location (Read Word 11, bits 00...15) for an echo of the EDT command.

If the EDT response word reads 80FF (Hex), repeat step 3. Make sure that you allow sufficient time for the module to respond to your request. If there is no change, calibration has failed. Check the wiring and try again.

#### **Channel Loop Compensation Calibration**

Each 2-wire RTD can be calibrated individually, or simultaneously. Proceed as follows.

- 1. Short circuit the end of each input cable at the RTD element. Do this for all channels to be calibrated.
- 2. Apply power to the module for 20 minutes before calibrating.
- Initiate a write to the module with 2403 (Hex) (calibrate all channels) in the EDT command location (Write Word 3, bits 00...15). For individual channel calibrations, use 04X3 (Hex) (0403, 0413, 0423...0473).
- 4. Monitor the EDT response location (Read Word 1X, bits 00...15) for an echo of the EDT command.

If the EDT response word reads 80FF (Hex), repeat step 3. Make sure that you allow sufficient time for the module to respond to your request. If there is no change, calibration has failed. Check the wiring and try again.

## **Notes:**

# **Troubleshoot the Module**

## **Overview**

## **Module Indicators**

This appendix provides a description of the different status indicators for the FLEX I/O Thermocouple, RTD, and mV module to help you troubleshoot.

The FLEX I/O module has one status indicator (PWR) that is on when power is applied to the module, and one fault indicator (F) for each input.



A - Insertable label for writing individual input designations

**B** - Fault Indicator - Indicates a noncritical fault

C - Power Indicator - Indicates that power is applied to module A

#### **Table 18 - Status Indicators**

Indicator	Color	State	Description
Fault	Red	On	At power-up – Channel 0 indicator lights at power-up until all internal diagnostics are checked. After successful power-up, the indicator goes off if no fault is detected and the module has started communicating with an adapter. After successful power-up – Indicates a critical fault, such as diagnostic failure. If the channel indicator stays solid red after power-up, there is an internal module error. Try cycling power. If the problem persists, replace the module. If the channel indicator continues to blink after power-up, communication between the module and the adapter has not been established.
		Blinking (when faults are enabled, and bit set)	Indicates a noncritical fault (such as an open sensor). Input is data set to maximum, and the indicator flashes at about 1 Hz rate.
Power		Off	Module not powered
	Green	On	Module receiving power

The FLEX I/O Thermocouple, RTD, and mV module returns diagnostics to the processor in Word 9 of the block-transfer read (BTR) file. These diagnostics give you information on the status or condition of the module.

Table 19 - Diagnostic Bits in Word 9

Word	Dec. Bits (Octal Bits)	Desc	Description								
		Diagr	Diagnostic Bits - Represent module configuration and/or hardware errors.								
		Bit	03	02	01	00					
			0	0	0	0	Reserved for factory use				
	0003		0	0	1	0	Improper module configuration				
			0	1	1	0	RAM fault				
			0	1	1	1	EEPROM fault				
			0001, 0100, and 00111111 Reserved for factory use								
Read Word 9	04	Series	s of Unit	(SAB) –	0 = Serie	es A, 1 = S	Series B				
	0506	Cold corre and th CJC1,	Cold Junction Compensation Fault Bits – These bits are set (1) when the corresponding cold junction compensator lead is broken, unattached, or shorted, and the thermocouple is set to "external compensation." Bit 05 corresponds to CJC1, and bit 06 to CJC2.								
	07	Not u	sed								
	0815 (1017)	Fault (broke value so on	<b>Alarm</b> I en, disco . Bit 08 (	<b>Bits</b> - Ar onnected 10) corre	n alarm I 1). If the esponds	oit is set alarm is to input	(1) when an individual input lead opens enabled, the channel reads maximum channel 0, bit 09 (11) to channel 1, and				

# **Electronic Data Sheet (EDS) Files**

#### **Overview**

EDS provides the definition for a device's configurable parameters and public interfaces to those parameters.

Every type of configurable device has its own unique EDS. It is a simple text file that allows product-specific information to be made available to third-party vendors.

This makes updating of configuration tools easier without having to constantly revise the configuration software tool.

With the following revisions, EDS files are required for RSNetWorx™ for DeviceNet® and ControlNet, RSLinx®, RSLogix 5, and Studio 5000 Logix Designer application to recognize a device:

RSNetWorx	Version 2.21
RSLinx	Version 1.10.176
RSLogix 5	Version 4.0
Studio 5000 Logix Designer	Version 20

## **Updating EDS File**

Most EDS files are installed with RSLinx, RSNetWorx, and other Rockwell Software<sup>®</sup> as long as you enable the option during installation.

There are instances where you will must acquire and register EDS files on your own even after all the software is installed.

- If you go online with RSNetWorx and it shows a device with a "?", a globe, or a message that says the device is unrecognized, this means the EDS file for that device **does not** exist on your PC.
- If RSLinx can see a processor but is not able to go online, upload, or download.

With ControlLogix modules the backplane **does not** show after expanding the tree or ControlLogix modules in the backplane show up as a yellow question mark without a red X sign.

An EDS file is also required if a bridge such as a 1756-CNB or DNB **does not** show the "+" sign to expand the tree to show its network.

You can download EDS files from the Product Compatibility and Download Center at <u>rok.auto/pcdc</u>. It allows you to search for devices by the type of network and their catalog number.

#### ATTENTION:

- Make sure to match the major firmware revision of the device as each major firmware revision is associated with a specific EDS file.
  - Download the EDS file and place it in any folder, except the /Program Files/ Rockwell Software/RSCommon/EDS folder where your Rockwell Automation software is installed.
  - Register EDS files with RSNetWorx by selecting Tools EDS Wizard.
  - Select Register an EDS File, then click the Browse button on the Next page to find your file.

#### **EDS Installation**

You can register EDS files with the EDS Hardware Installation tool.

- 1. In Windows<sup>®</sup>, go to Rockwell Software -> RSLinx Tools -> EDS Hardware Installation Tool.
- 2. Click Add to register an EDS file.

When an EDS file is registered, a copy of the file is made and placed in the /RSCommon/EDS folder, where your Rockwell Automation software is installed and your Windows registry is updated. Once the registration is complete you can move, copy, or delete the original files.

#### ATTENTION:

- Only one EDS file is required to support both the Series A and Series B modules. The module ID for the Series A and B is identical because there is no change in software functionality.
- The Series B hardware jumper determines how the module data reacts to an open circuit condition.
- Download the Series A and B EDS file from the Product Compatibility and Download Center at <u>rok.auto/pcdc</u>.
- The EDS file is installed using the RSLinx Tools EDS Hardware Installation Tool.

# **Program Your Module with PLC Family Processors**

Overview	This appendix server modules.	es as a reference to users of the PLC Family Processors to program their					
	To initiate commun processor, you mus chapter to enter the	ication between the Thermocouple, RTD, and Millivolt modules and your PLC st enter block transfer instructions into your ladder logic program. Use this e necessary block transfer instructions into your ladder logic program.					
Enter Block Transfer Instructions	The Thermocouple, bidirectional block t instructions.	RTD, and Millivolt modules communicate with the PLC processor through transfers. This is the sequential operation of both read and write block transfer					
	Before you configue The following exam communication to t modified to suit you	re the module, you must enter block-transfer instructions into your ladder logic. ple programs illustrate the minimum programming that is required for take place between the module and a PLC processor. These programs can be ar application requirements.					
	A configuration block-transfer write (BTW) is initiated when the frequency module is first powered up, and then only when the programmer wants to enable or disable features of the module. The configuration BTW sets the bits that enable the programmable features of the module, such as scalars and alarm values. Block transfer reads are performed to retrieve information from the module.						
	Block-transfer read (BTR) programming transmits status and data from the module to the processor data table. The processor user program initiates the request to transfer data from the module to the processor. The transferred words contain module status, channel status, and input data from the module.						
	Your program should monitor status bits, block-transfer read and block-transfer write activity.						
	PLC-2 Family	Processor					
	The FLEX Thermoco family programmat	ouple, RTD, and Millivolt modules are not recommended for use with PLC-2® ole controllers due to the number of digits needed for high resolution.					
	<b>IMPORTANT</b> The Thermocouple, RTD, and Millivolt modules function with reduced performance in PLC-2 systems. Because the modules do not support BCI and the PLC-2 processor is limited to values of 4095 (12 bit binary), many values that are returned in the BTR file may not provide meaningful data the PLC-2 processor.						
	PLC-3 Family	Processor					
	Block transfer instr	uctions with the PLC-3® processor use a control file and a data file. The block					

Block transfer instructions with the PLC- $3^{\circ\circ}$  processor use a control file and a data file. The block transfer control file contains the data table section for module location, the address of the block transfer data file and other related data. The block transfer data file stores data that you want transferred to the module (when programming a BTW) or from the module (when programming a BTR).

The programming terminal prompts you to create a control file when a block transfer instruction is being programmed. The same block transfer control file is used for both the read and write instructions for your module. A different block transfer control file is required for every module.



The IRT8 module is located in rack 3, I/O group 2, slot 1. The control file is a 10 word file starting at B17:0 that is shared by the BTR/BTW. The data sent by the PLC-3 processor to the IRT8 module is from PLC memory starting at N18:1, and with the default length of 0, is 4 words long.



#### **PLC-5 Family Processor**

Block transfer instructions with the PLC-5 processor use a control file and a data file. The block transfer control file contains the data table section for module location, the address of the block transfer data file and other related data. The block transfer data file stores data that you want transferred to the module (when programming a BTW) or from the module (when programming a BTR).

The programming terminal prompts you to create a control file when a block transfer instruction is being programmed. A different block transfer control file is used for the read and write instructions for your module.

#### PLC-5 Processor Rung 2:0

Program Example The IRT8 module is located in rack 2, I/O group 2, slot 1. The integer control file starts at N22:200, is 5 words long and is compatible with all PLC-5 family members. The data obtained by the PLC-5 processor from the IRT8 module is placed in memory starting at N22:101, and with the default length of 0, is 11 words long. The length can be any number



#### PLC-5/250 Family Processor

Block transfer instructions with the PLC-5/250 processor use a control file and a data file. The block transfer control file contains the data table section for module location, the address of the block transfer data file and other related data. The block transfer data file stores data that you want transferred to the module (when programming a BTW) or from the module (when programming a BTR).

The programming terminal automatically selects the control file based on rack, group and module, and whether it is a read or write. A different block transfer control file is used for the read and write instructions for your module. A different block transfer control file is required for every module.

#### PLC-5/250 Processor Program Example

#### Rung 1STEPO:1

The IRT8 module is located in rack 14, I/O group 1, slot 0. The data obtained by the PLC-5/250 processor from the IRT8 module is placed in the data table starting at 2BTD5:101, and with the default length of 0, is 11 words long. The length can be any number between 0 and 11.



#### Rung 1STEPO:1

The IRT8 module is located in rack 14, I/O group 1, slot 0. The data sent to the IRT8 module from the PLC-5/250 processor is from the data table starting at 2BTD5:1, and with a default length of 0, is 4 words long. Valid BTW lengths: 0, 1, 2, 3, and 4.



# **Resolution Curves for Thermocouples**

Use the resolution curves to help select the proper operating range of your thermocouple. They show the resolution that the module provides internally depending on thermocouple type and filter selection. The lower the resolution, the higher the accuracy. Note that the maximum resolution displayed is 0.1  $^{\circ}$ C (32.18  $^{\circ}$ F).

## **Type B Thermocouple**



### **Type E Thermocouple**



Type C Thermocouple



## Type J Thermocouple







### **Type R Thermocouple**



## **Type S Thermocouple**



## **Type T Thermocouple**



## **Type N Thermocouple**



# Type TXK/XK(L) Thermocouple



#### Numerics

1756-CNB 45 1756-ENBT 21 1794-ACN15 8 1794-ACNR1 8 1794-ACNR15K 8 1794-ADN 8 1794-AENT 8, 21 1794-APB 8 1794-APBDPV1 8 1794-ASB 8 1794-CJC2 8 1794-IRT8 7, 9, 11, 33 Series A 11 Series B 11, 37 1794-IRT8XT 7 Series B 11 1794-TB3G 11, 16, 17, 18, 33, 35 wiring 36 1794-TB3GK 17, 18 1794-TB3GS 11, 16, 17, 18, 33, 35 wiring 36

#### A

accuracy 51 adapter 7, 14, 15 alignment bar 16 alignment groove 16 Allen-Bradley 35 analog signals 8

#### В

backplane 11, 16 base unit 16 bipolar 25 bit CJC status 11 bits CJC alarm 11 CJC fault 29, 44 data format 25, 30 EDT 30 EDT command 33 EDT data 33 fault alarm 29, 44 fault mode 30 input type 32 input types 26 overrange alarm 28 reference junction 26 sensor mode 26, 31, 32 sensor type 26, 32 underrange alarm 28 block-transfer read 28, 47 1794-IRT8 28

block-transfer write 27, 28, 35, 47 type and input range selection 27 block-transfers 47 BTR 35, 44, 47, 48, 49 BTW 35, 47, 48, 49

## C

calibration 26, 33, 35, 39 CJC 38 cold junction 40 Cold Junction Compensation 37 current source 40 EDT command 38 EDT commands 39 environment 35 equipment 35 gain 38, 39 general 38 manual 35, 36 offset 38, 39 periodic 35 power supply 35, 39 preparation 35 procedure 35 read words 37 setup 36 setups 36 temperature 35 tool 35 tools 35 types of 35 using resistors 36 write words 37 cap plug 16 channel 23 channel loop compensation 26 chassis 11, 17, 18, 37 chassis Ground 18 CJC 17, 26, 28, 38, 40 disconnecting 18 fault 44 sensors 31, 32 CJC Alarm bit 11 CJC compensation 27 CJC sensor 18 CJC tail 18 cold junction calibration 40 Cold Junction Compensation 18, 24, 26, 29, 37 **Cold Junction Compensators** 17 cold junction compensators 8 combination wiring 12 commands EDT command data 38 common mode range 11 communication between module and adapter 8 CompactLogix 21

compensation 2-wire 24 2-wire with Loop 24 external 31, 32 internal 31, 32 condition 44 configurable options 25 data format selection 25 fault mode 26 input filter 25 input types 26 reference junction 26 RTD offset 26 sensor mode 26 sensor type 26 configuration 8, 25 input range 25 configuration parameters 23 connectina wirina 36 controller 21 ControlLogix 21, 45 ControlNet 9, 11, 21 current draw 12 current source calibration 40 curves resolution 51

## D

daisychain 12, 17 data format 23, 24 bipolar 25 unipolar 25 data formats 25 data table 25 default 25 detection overrange 8 underrange 8 wire-off 8 diagnostic bits 29, 44 status 37 diagnostics 43, 44 differential compensation 24 digital module 12 DIN rail 7, 13, 14 specification 13 drilling dimension 15 drilling points 14

#### Ε

EDS 45 installation 46 EDT 30, 33, 38 command 39, 40 data response 30 response 40 response location 39, 40 EDT command 29, 39 enclosure 11 equipment 35 EtherNet/IP 9, 11 adapter 21 external 26 external compensation 24

#### F

fault alarm 44 channel 28 EEPROM 44 RAM 44 Fault alarm 29 fault detection 25 fault mode 26 features software 25 filter single pole 25 firmware 11 FLEX I/O 35 components 7 millivolt 11, 25 RTD 11, 25 system 14, 35 thermocouple 11, 25 FLEX system 7 Flexbus 8, 13, 14, 16 female connector 13 Flexbus connector 16 frequency input indicators 43

## G

gain 35, 36, 39

## H

hazardous location 16 humidity 35

#### 

I/O module 7 individual wiring 12 input channels 35 designators 9 input filter 23, 24 input type 31, 32 input types default 26 inputs 8 resistive 7

#### installation

connecting wiring 12 hazardous location 16 instructions 11 mounting 12 requirements 11 terminal base 14 **internal** 26 **internal compensation** 24 **isolation mode** 11

#### K

keyswitch 11, 16

## L

ladder logic 35, 47 Latching mechanism 16 Logix system 9 loop compensation 33 low pass 25

#### M

male connector 13 manual 35 manual calibration 35 mapping 1794IRT8 28 message fault 36 Millivolt 47 millivolt 26, 35 calibration 36 millivolt wiring 19 module status 44 module label 9 mounting wall or panel 14 mounting kit 14 **MSG instructions** 9 **mV** 26 mV source 8

## 0

offset 35, 36 offset calibration 39 offsets 39 ohmmeter 17, 18 open sensor 43 overrange 26

#### Ρ

PLC 5 21 PLC family processors PLC-5 48 PLC processor 47 **PLC processors** PLC-2 47 PLC-5/250 49 PLC-\* Family Processors 47 PLC-2 system 47 PLC-2 family processor 47 PLC-3 control file 47 data file 47 PLC-3 processor 47 PLC-5 controller 21 PLC-5 processor 48 PLC-5/250 control file 49 data file 49 PLC-5/250 processor 49 power 35 connections 12 operational 11 precision millivolt 39, 40 preparing for calibration 35 processor 25 processors 35 programming 47

## R

read programming 27 read words decimal 37 octal 37 overrange bits 29 underrange bits 29 recalibration 35 reference junction 30, 32, 37 default temperature 26 reference junction selection 31 Remote 1/0 11 **Requested Packet Interval 22** resistance 26, 31, 32 resolution 51 resolution curve 51 type B 23 type B thermocouple 51 type C thermocouple 52 type E 23 type E thermocouple 52 type J 23 type J thermocouple 53 type K 23 type K thermocouple 53 type N 23 type N thermocouple 55 type R 23 type R thermocouple 54 type S 23 type S thermocouple 54 type T 23 type T thermocouple 55 type TXK/XK(L) thermocouple 56 type TXK/XKL(L) 23 **RSLinx** 45, 46 **RSLogix 5** 45

**RSNetworx** 45 RTD 8, 23, 24, 27, 31, 35, 37, 47 2-wire 31, 32 3-wire 24, 31, 32 3-wire connection 18 4-wire 24, 31, 32, 36 4-wire connection 17 disconnecting 18 fault mode 26 isolators 27 loop channel compensation 38 offset 26 wire pairs 17 **RTD** analog input mapping 1794IR 28 **RTD mode** open circuit 26 short circuits 26 RTD offset 26, 29, 33, 37 RTD Wire Pairs 17 RTD wire pairs 17 3-wire RTD 18 4-wire RTD 17

#### S

connecting 17

sendor mode 26 Sensor 23 sensor 23 mode 31 RTD Type 27 RTD type 32 thermocouple type 27, 32 type 26, 31, 32 types 27 sensor mode 23, 24, 29, 37 Sensor Type 31 sensor type 23, 29 sensors CJC 31 Series A 11, 33 Series B 11, 33 signal wiring 17 signals analog to binary conversion 8 **SLC** 21 status indicator fault 43 power 43 Studio 5000 Logix Designer 9, 11, 21, 45

#### Т

temperature 26 ambient 26 terminal base 7, 11, 13, 15 installation 14 mounting 12 wiring 12 Thermocouple 23, 35, 37, 47

#### thermocouple 8, 24, 26, 27, 31

resolution curve 51 type 31 type B 51 type C 52 type E 52 type J 53 type K 53 type N 55 type R 54 type S 54 type T 55 type TXK/XK(L) 56 types 51 thermocouple mode 11 thermocouples 26 tool precision resistors 35 precision voltage source 35 tools calibration 35 interconnect cable 35 troubleshoot 43 types 25

#### U

unipolar 25

## W

wiring 12, 14, 17, 36 connections 36 terminal base 12 wiring connections 1794IRT8 36 write word RTD Type 31 write words data format 37 filter time constants 30 input type 31 sensor mode 32 sensor type 32

# **Rockwell Automation Support**

Use these resources to access support information.

Technical Support Center	Find help with how-to videos, FAQs, chat, user forums, Knowledgebase, and product notification updates.	rok.auto/support
Local Technical Support Phone Numbers	Locate the telephone number for your country.	rok.auto/phonesupport
Technical Documentation Center	Quickly access and download technical specifications, installation instructions, and user manuals.	rok.auto/techdocs
Literature Library	Find installation instructions, manuals, brochures, and technical data publications.	rok.auto/literature
Product Compatibility and Download Center (PCDC)	Download firmware, associated files (such as AOP, EDS, and DTM), and access product release notes.	rok.auto/pcdc

## **Documentation Feedback**

Your comments help us serve your documentation needs better. If you have any suggestions on how to improve our content, complete the form at <u>rok.auto/docfeedback</u>.

## Waste Electrical and Electronic Equipment (WEEE)



At the end of life, this equipment should be collected separately from any unsorted municipal waste.

Rockwell Automation maintains current product environmental compliance information on its website at rok.auto/pec.

Allen-Bradley, CompactLogix, ControlLogix, expanding human possibility, FactoryTalk, FLEX, Logix 5000, PanelView, PLC-2, PLC-3, PLC-5, Rockwell Automation, Rockwell Software, RSLinx, RSLogix 5000, RSNetWorx, SLC, Studio 5000 Logix Designer, and TechConnect are trademarks of Rockwell Automation, Inc.

ControlNet, DeviceNet, and EtherNet/IP is a trademark of ODVA, Inc.

Windows is a trademark of Microsoft Corporation.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş. Kar Plaza İş Merkezi E Blok Kat:6 34752, İçerenköy, İstanbul, Tel: +90 (216) 5698400 EEE Yönetmeliğine Uygundur

Connect with us. 👍 🞯 in 😏

#### rockwellautomation.com

expanding human possibility<sup>®</sup>

AMERICAS: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444 EUROPE/MIDDLE EAST/AFRICA: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2663 0600, Fax: (32) 2 663 0640 ASIA PACIFIC: Rockwell Automation SEA Pte Ltd., 2 Corporation Road, #04-05, Main Lobby, Corporation Place, Singapore 618494, Tel: (65) 6510-6608, Fax: (65) 6510-6609 UNITED KINGDOM: Rockwell Automation Ltd., Pitfield, Kiln Farm, Milton Keynes, MK11 3DR, United Kingdom, Tel: (44)(1908) 838-800, Fax: (44)(1908) 261-917